



2018 & Up Jeep Wrangler JL/JLU Custom Antenna Mount (Drivers Side)

Installation time ~ 10 minutes

Features:

Made from 1/4in 301 Stainless Steel
Pre-Drilled 1/2in Antenna Hole
Compatible with 1/2 in Firestick Quick Connect
Compatible with all 1/2in antenna bulkheads
Drillable to 3/4in with contoured platform for NMO
mount and antennas (Titanium Step Drill Bit
Recommended)

Disclaimer: We are not responsible for damage due to improper installation or installation procedures.

Warning: While it may not be necessary to remove the spare tire for installation, we recommend doing so for safety reasons. You are removing 2 of the 8 bolts (or 25% of them) holding your spare tire to install this mount. Should the weight of your tire be too much for the remaining 6 bolts to hold, there would be a risk of injury and damage.

Contact Information

Kraken Offroad Products

8761 N. 56th St #16960

Temple Terrace, FL 33617

Email: Sales@KrakenOffroad.com

Web: <https://KrakenOffroad.com>

Passenger Side

1. Remove the bolts in the image below



2. Install the bracket in the location below, using the hardware you removed in step 1



Drivers Side

1. Remove the bolts in the image below



2. Install the bracket in the location below, using the hardware you removed in step 1

